

# Quick Installation Guide

5~15kW Three Phase Storage Inverter

1. Packing List

Inverter x1

Bracket x1

Expansion tubes x6 & Expansion screws x6

Hexagonal screws x3

Earth terminal x1

AC connectors x1

Battery connectors (positive x1, negative x1)

PV pin connectors (Only for Hybrid) (positive x3, negative x3)

Communication connector x1

3ph Meter <80A x1

PV pin contacts (Only for Hybrid) (positive x3, negative x3)

Installation Guide x1

Ethernet cable terminal x4

Battery pin contacts (positive x1, negative x1)

Antenna x1

## 2. Mounting Steps

Step 1: Please make sure the inverter will be installed with a proper distance as shown below.

Step 2: Select the installation location, place the bracket on the wall, and mark the hole positions.

Step 3: Drill the 6 holes with a ø8 drill bit. Depth at least 50mm. Hammer the expansion tubes.

Step 4: Lock the screws on the side (left and right). Make sure the inverter is firmly attached.

Step 5: Match the inverter with wall bracket.

Step 6: Lock the screws on the side (left and right). Make sure the inverter is firmly attached.

## 6. BAT connection

Step 1: Prepare BAT wire. We recommend to use the original Bat-Inverter power cable and communication cable from Battery's accessory bag. If require a longer cable, please contact our sales representative to purchase.

Step 2: Connect the power line and communication line between the BMS and the inverter.

Step 3: Connect the grounding cable to ensure that all batteries are grounded. Wiring shall be connected in the sequence as shown in below.

The connection between BMS and inverter should be less than 10m.

NOTE: The number of battery packs cannot be less than 3 pcs.

7. Grounding connection

Grounding Wiring

Step 1: Prepare ground wire.

Step 2: To insert Earth terminal. Press the wire and terminal tightly with a wire clamp.

Step 3: screw the ground screw with screwdriver as shown below.

8. Firmware Update

Preparation: Please ensure the inverter is powered on with steady PV/BAT and AC power. Please prepare a PC and an U-Disk. Please note the U-Disk shall be less than 32GB and its formats is fat16 or fat 32. Please DO NOT apply USB3.0 U-Disk on USB port, the inverter USB port only support for USB2.0 U-disk.

Step1: Please contact our service support to get the update files, and extract it into your U-Disk as follow: update/master/ H3\_G2\_Smart\_Master\_Vx.xx.bin update/slave/ H3\_G2\_Smart\_Slave\_Vx.xx.bin update/manager/ H3\_G2\_Smart\_Manager\_Vx.xx.bin

NOTE: Vx.xx is version number.

Step 2: Unscrew the waterproof lid and insert U-disk into the "USB" port at the bottom of the inverter.

Step 3: The LCD will show the selection menu. Then press up and down to select the one that you want to upgrade and press "OK" to confirm to upgrade.

Step 4: After the upgrade is finished, pull out the U-disk. Screw the waterproof lid.

24PIN Wiring Installation Procedure

Step 1 Remove the plug inside the plug and thread the terminal according to the sequence shown in the illustration.

Step 2 Insert the wires into the corresponding terminals.

Step 3 And use a screwdriver to crimp the wire, screwing torque 12+/-0.1N.m.

Step 4 Arrange the core line, the rubber core areamust not appear to ride the line. The rubber core is loaded into the main body and accompanied by a "click" sound.

Step 5 Install the plug into the main body and plug the holes without wires with a plug.

Step 6 Lock wire nut screwed onto the body, torque 2.5+/-0.1N-m, then complete installation.

II. Inverter Start-Up

Please refer to the following steps to start up the inverter.

1. Ensure the inverter fixed well.
2. Make sure GRID and EPS wirings are completed.
3. Make sure the PV wirings is connected well.
4. Make sure the meter is connected well.
5. Make sure the battery is connected well.
6. Make sure the BMS buttons and battery switch are on.
7. Ensure accurate installation of the monitoring module to the inverter. (Refer to the installation of the monitoring module)
8. Turn on the PV/DC switch (for Hybrid version only), AC breaker, EPS breaker and battery breaker.
9. Check whether each voltage is normal and within the operating range of the machine through the screen on the machine.
10. If the main page shows "switch off", please long press "-" bottom to quickly go to the START/STOP page and set it to start. (Enter the settings page, default password is "0000").

NOTE: When starting inverter for the first time, the country code will be set by default to the local settings. Check if the country code is correct. Set the time on the inverter using the button or by using the APP.

3. GRID Connection

Step 1: Prepare AC wire. Cable is a five-core cable with a diameter less than 9-16 mm. Cross-sectional area of wire is shown in the following table.

Modell (kW)	5.0	6.0	8.0	10.0	12.0	15.0
Cable (GRID)	4.0mm²	4.0mm²	6.0mm²	6.0mm²	6.0mm²	6.0mm²
Cable (EPS)	4.0mm²	4.0mm²	6.0mm²	6.0mm²	6.0mm²	6.0mm²
Micro-Breaker	20A	20A	25A	25A	32A	32A

Step 2: Dimension of stripping line  
Dimension of stripping line outside machine

Step 3: Wiring Precautions

Step 4: Seal accessory option  
A. Ø18: The recommended outer diameter of the cable is 17.5-18.5mm.  
B. Ø21: The recommended outer diameter of the cable is 19-21mm.  
C. Ø6: When the four wire system is used, the special hole for the ground wire is recommended to be applicable to the outer diameter of the cable. (5-6mm)

NOTE: If the outer diameter of the cable is greater than 18mm, remove part 1. When 4-core wire is used, Ø6 holes are ground wire through holes. Remove part 3.

Installation steps for 5-core wire  
Thread the stripped wire into the lock nut and the main body in turn. (the flexible wire needs to be riveted to the insulated terminal)

First, insert the EPS end cable into the EPS end of the rubber core. After the cable is in place through the perspective hole, tighten the screw using an S2.5 hexagon wrench with a torque of 2.5±0.1N.m.

Insert the GRID end-core wire into the GRID end of the rubber core, observe the perspective hole cable in place, use S2.5 hex wrench to tighten the screws, torque 2.5±0.1N.m.

Insert the main body into the rubber core and hear the "click" sound.

Seal plug in main body.

Tighten the nut with an open-ended wrench. (torque 10.0±0.1N.m. Complete the installation)

Inserted  
Open the latch.

Align the female end with the male end in the anti-stay position.

After the male and female insert the card point into the tracks lot, press the lock.

Tighten the screws with the S2.5 hexagon wrench with a torque of 2.5±0.1N.m. Installation completed.

4. EPS Connection

EPS wiring diagram

For countries such as China, Germany, the Czech Republic, Italy, etc., please follow local wiring regulations. This diagram is an example for an application in which neutral is separated from the PE in the distribution box.

For countries such as Australia, New Zealand, South Africa, etc., please follow local wiring regulations. According to Australian safety requirements, the N cables of the GRID side and EPS side must be connected together. Otherwise, the EPS function will not work.

5. PV connection

PV Wiring (For Hybrid Only)

Step 1: Prepare PV wire. Choose 2.5mm² wire to connect the PV module. Trim 6mm of insulation from the wire end.

Step 2: Separate the PV connector as below.

Step 3: To insert terminal. Press the wire and terminal tightly with a wire clamp. Rivet terminal. Ensure the concave-tnicity of metal parts and cable at same level/crimped metal parts and cable pull tension 230N.

Step 4: Insert pin into the male or female plug. Until hear a "click". Tighten the nut on the terminal.

9. RJ45 connection

The machine has three RJ45 terminals, which are meter, Ethernet, and DRM functions

The definition of meter port pin is as follows:

PIN	1	2	3	4	5	6	7	8
meter	meter 485B	meter 485A	/	/	/	/	meter 485B	meter 485A

The definition of Ethernet port pin is as follows:

PIN	1	2	3	4	5	6	7	8
Ethernet	TX+	TX-	RX+	/	/	/	RX-	/

The definition of DRM port pin is as follows:

PIN	1	2	3	4	5	6	7	8
DRM	+3.3V	DRM1	DRM2	DRM3	DRM4	DRM5	GND	GND

RJ45 Wiring

Installation Procedure of the RJ45 Connector

Step 1 Insert the network cable into the wire-locking nut, sealing plug and mainbody in turn. The sealing plug is stuck into the network cable through the gap on the sealing side.

Step 2 Insert the network cable plug into the matched RJ45 panel mount connector.

Step 3 Tighten the connector mainbody by an open-ended wrench into the RJ45 panel mount connector with a torque 12±0.2N.m.

Step 4 Insert the sealing plug into the main body of RJ45 cable end connector.

Step 5 Tighten the connector's nut by an open-ended wrench with a torque 12±0.2N.m.

CT-Meter Type

Step 1: Insert L1/L2/L3/N wires, CT and RS485A/B cable into the meter. Please refer to the meter wiring diagram on side of meter itself. During CT use, the direction of the CT arrow faces the inverter.

NOTE: If there is only one 485 port, there is no 5 or 12 terminal.

Step2 Connect RS485A to pin 2/8 of the inverter METER/RS485 port. Connect RS 485B to pin 1/7 of the inverter METER/RS485 port. Please use twisted pair cable.

PIN	1	2	3	4	5	6	7	8
meter	meter 485B	meter 485A	/	/	/	/	meter 485B	meter 485A

Step 3: The transformation ratio setting of a CT meter needs to be consistent with the transformation ratio of a CT meter. The transformation ratio setting method for a CT meter is as follows:

Introduction to Ethernet port:

The network port is mainly used for communication, transmitting data from the inverter to the network for detecting the daily operation status of the machine, and can control the inverter's wake-up through EMS.

The device supports zero configuration network discovery through the mDNS (Multicast DNS) protocol. Users can directly access device services through standard format hostnames in the same LAN environment:

1. Service identification format:  
The device will broadcast the mDNS service in mDNS \_ < SN > format (e.g. mDNS \_ 12345678), and SN is the unique serial number of the device. (see fuselage nameplate label)  
Protocol Type: TCP  
Open port: 502 (default for Modbus TCP industrial communication protocol)

2. Precautions:  
Please make sure the device is on the same subnet as the client;  
Please close the firewall or release UDP 5353 (mDNS) and TCP 502 ports;  
Please refer to the SN number of the equipment for serial number.

Ethernet connection Diagram

DRM port  
DRM is mainly used to implement the Ripple Control function. The prerequisite for the use of this function is the selection of the German grid connection regulation VDE 4105 and Austria code the use of the RCR function.

The ripple control function is described below:

Switching state	Output active power (xPn)
No contact closed	100%
Several contacts closed	100%
Contact DRM 1 to +3.3V	60%
Contact DRM 2 to +3.3V	30%
Contact DRM 3 to +3.3V	0%
Contact DRM 4 to +3.3V	Immediate OFF
Contact DRM5 to 3.3V	AC Max.Chr power limit to 4.2kw under Vde4105 Safty

10. COM connection

Introduction to COM port:

The COM port mainly includes EMS485, Meter485, WiFi485, Estop port, two relay output ports, two parallel ports and a toggle switch, +12V and corresponding relay output signals.

The ripple control function is described below.

EMS 485: Supports Modbus485 communication, which can be used to read and control machines. The specific protocol is provided by the manufacturer.

Meter 485: Similar to the Meter485 interface, this interface is designed to be redundant.

Wifi 485: For internal testing.

Estop port: When short circuiting ESTOP and GND, the machine will stop working.

DY OUT: The machine has two DY OUT interfaces, with two internal contacts of relays hat can drive loads of 230VAC1A/50VDC0.5A, and can be used for powering on and starting heat pumps.

PARA port RJ45: Used for parallel communication, it is necessary to set the DIP switch to the ON state during parallel operation. +12V and RV-Out are used to control external relay switches and cannot be used for other functions.

12. Wifi Stick Installation

1 Wifi Stick Installation

Alarm: The collector can only be plugged into the inverter, not any other device.

Step 1: Please make sure the antenna is installed correctly.

Step 2: Power on the inverter (in accordance with the start-up procedure detailed in the inverter installation manual).

2 App Installation and Wifi Configuration

Scan the QR Code below to download and install the FoxCloud APP on your smartphone, refer to the "APP2.0 QUICK GUIDE" page for Wifi distribution network instructions.

NOTE: Contains app download path, configuration process, etc.