
Victron Energy DC-DC converters Orion

1. Install in a cool, dry and well-ventilated place.
2. First connect the negative pole of the power cable to one of the negative terminals on the Orion. Both negative terminals are interconnected. Please note that a poor negative connection could lead to overvoltage at the output.
3. Then connect the INPUT wiring and install a fuse on it. At this point, make sure that the output voltage is correct. If it is, you can safely connect the device to the OUTPUT, again through a fuse. (The recommended fuse rating is equal to the output current.)
4. The Orion is now ready for use.



Warning!: the current can be very high. Always use cables with a sufficient cross-section!
Warning!: install a fuse on both the input and output. If no input and output fuse is used, the warranty cannot be accepted.

