

Aladdin self-venting valve

Suitable for standard panel and bathroom radiators with 1/2 BSP thread. Works on both open and closed systems.

Contents: 1x Aladdin HV30C valve, 1x U-key (inside the dust cap)

Please read these instructions carefully before installation. Failure to do so may void the warranty.

Installation:

- The valve will work faster if it is installed on the warmer, flow side of the radiator.
- Use a suitable spanner to fit the valve, but do not overtighten it.
- Although the O-ring provides sufficient sealing and no tape or sealant is required, a small amount of PTFE tape may be used if necessary.
- **Use the U-wrench only after filling the radiator**

for the first time. After the first filling:

- If you want to drain the radiator and there is no internal pressure in the system, use the U-wrench in the holes in the cartridge and loosen the valve by half a turn to allow air to enter the system.
- To refill after draining, either wait up to 6 hours for the valve to return to automatic operation or manually vent using the U-wrench.
- The valves have a guaranteed service life of 5 years, after which, if the radiator collects air, you can purchase a replacement cartridge from your local dealer.