




User Guide for the Huawei FusionSolar app




1. AppGallery

- The first step is to download the AppGallery app (a Huawei app) from Google. Download link:
- <https://appgallery.huawei.com/Featured>



2. FusionSolar

- Once AppGallery is installed, you need to download the FusionSolar app. Alternatively, you can download FusionSolar directly via this link:
- <https://eu5.fusionsolar.huawei.com/pvmswebsite/app.html>



3. Log in



- You will then need to log in to FusionSolar.
- You log in using your email address.
- You will receive an invitation to the FusionSolar app via email, where you will find your initial login password. Once logged in, the app will ask you to set a password of your choice. Don't forget to make a note of it somewhere so you don't have to reset it again.
- The invitation is valid for 7 days; after that, it will be deactivated and you will need to call our technical support team here at ECOprodukt so that we can reactivate it for you!

4. First steps

After logging in, you will see a screen like this:

Explanation:

- 1. Today's energy generated
- 2. Money saved today
- 3. Indicator showing the rate at which the battery is discharging or charging
- 4. A positive number indicates how much energy you are drawing from the grid; a negative number indicates how much energy you are feeding into the grid
- 5. Current household consumption
- 6. Battery charge percentage
- 7. Current energy generation from the panels







5. Devices

- In the ‘Devices’ column, you can see the devices connected to your power plant.


6. Inverter

- When you click on ‘Inverter’, a window will appear where you can view: basic information about the inverter, historical data including graphs that you can customise to suit your needs, and real-time information.




7. My Account

- Clicking on the “Me” tab will open a window displaying basic details about your account. Here, you can set (Plant management) the power plant name, address and other details.




8. Wi-Fi network

- If you have changed your home Wi-Fi router, you must connect the inverter to the new Wi-Fi network. You can do this in the ‘Me’ section under ‘Commission Device’ as follows:
- Select the ‘PV Product’ option
- Click on the third icon from the top left (the inverter image)




9. Scan the QR code

- **Scan the inverter's QR code located on the right-hand side, then connect to the SUN2000xxx-xxxx inverter's Wi-Fi**




10. Settings

- **Once connected to the inverter via the QR code, the settings menu will appear; select the 'Settings' option.**



11. Communication configuration

- Once the settings are open, a menu will appear; select 'Communication configuration'.



12. Wi-Fi connection

- Next, select the 'Router connection settings' option.
- In the final step, select 'WLAN connection', enter your home Wi-Fi details and confirm the password for your home Wi-Fi network.

